

METHOD STATEMENT FOR CLAMPING

1. Wearing correct PPE i.e. gloves and eye protection.
2. Place clamps across belt on slack end and secure against rigid points on conveyor.
3. Pull other end until belt is tight.
4. Place second clamp against rigid point and secure.
5. Release tension.